


READ THIS DATA SHEET CAREFULLY PRIOR TO COMMENCING ANY INSTALLATION OF LIGHT FITTINGS

Ionic 1600 Wall / Ceiling Collections Data and Installation Sheet


- Materials** Aluminium, opal Acrylic, walnut timber
- Dimensions** L 1600mm x W 150mm x D 60mm - Wood Disk (150mm)
- Fixings** Standard wall canopy supplied. Fixing techniques may vary depending on wall surface and material. 5 mm
- Lamp Type** 24v DC LED Flexistrip with Tridonic 24v DC Non Dimmable or Dimmable on (DALI, DSI, SwitchDim) Driver. (Supplied with fitting.)
- Weights** 2.3kg

Installation


- Be careful when handling the wall light as powdercoat surfaces and timber surfaces can be marked easily. Before removing fitting from packaging please remove any other straps. Leave protective plastic cover on fitting while preparing for installation. **DO NOT stack the wall lights once they are unpacked from their boxes, as the weight of the stack will damage and mark the fitting**
- Remote mount driver into wall cavity behind bottom puck. Connect 240 V into driver first. If using a dimming system ensure that 5 core cable is used and connect dimming control lines, as shown below. Ensure driver has been approved and installed by a certified electrical contractor. Follow installation guide.
- The LED is polar sensitive, so make sure the + and - cables from the timber back plate to driver and fix in place in the correct position. Test fitting illuminates prior to fixing to wall. Attach timber back plate and illuminated section to wall with appropriate screw mountings. Now mount the top puck back plate to the wall with same mechanical fixings - Set down 200mm from top of light bar (see Diagram)
- Once the timber back plate is in place and secured, place the Ionic timber front plate by aligning the timber dowels and pushing until the front and back plate touch.
- Do not apply excessive force to fitting or fixtures and remember to remove protective plastic cover prior to turning on.
- If the fitting is required to be dimmable, please ensure that the driver is connected to either a DALI or Switchdim control unit. **Please turn to next page for reference diagrams and maintenance instructions.**



Non dimmable Remount mounted 24Volt Constant Voltage driver.
LED is polar sensitive ensure fitting is working correctly prior to installing.



DALI dimmable Remount mounted 24Volt Constant Voltage driver.
LED is polar sensitive ensure fitting is working correctly prior to installing.



Please contact Satelight if you have any questions regarding the steps included in this data sheet.

Cleaning • Do not use abrasive cleaning materials on fixture. Do not wipe fitting surfaces with wet cloth. Dust only.


• Please be aware that the shade materials are delicate and can scuff or mark easily.

Satelight Design Pty Ltd
www.satelight.com.au
96 Hudsons Road, Spotswood VIC 3015 Australia
Telephone +61 3 9399 5805
© Copyright Satelight Design Pty Ltd



Ionic Wall 1600 - Installation Guide


Step 1




Check that the fitting supplied matches the lighting schedule and that the direction of light is correct ie Front, Side or Back facing

Create a 50 x 40mm cutout for the 35W Driver in the wall/ceiling. The cutout for the driver needs to remain within the screw hole dimensions. The power puck is to be mounted on the bottom of the fitting. Use template guide provided. Align template to vertical and then align fitting to the required angle.

Connect driver to 240 V mains power coming from wall or ceiling. Then connect Driver 24V end to light fixture. Secure driver in wall or ceiling cavity away from insulation. Test the fixture to ensure all is working. Do not put physical strain on electrical leads.



Step 2



Once back plate power puck is firmly secured to the wall with appropriate mechanical fixings for the substraight, then from the top carefully slide down top puck along the light bar close to the wall. Careful not to damage the wall or light bar. The top puck is not fixed to the light bar and can be placed anywhere along the light bar as long as there is a minimum of 400mm C to C between the power puck and the top puck. For even spacing set puck down 200mm from top of light bar to top of puck backplate.


Align holes on back of front plate with the two timber dowels on the back plate and evenly push front plate on until it touches the back plate



www.satelight.com.au
info@satelight.com.au
96 Hudsons Road, Spotswood Vic 3015
Telephone +61 3 9399 5805


Ionic Wall 1600 - Installation Guide

Step 3




Once back plates are firmly secured to the wall with appropriate mechanical fixings for the substraight, Align holes on back of front plate with the two timber dowels on the back plate and evenly push front plate on until it touches the back plate

Finish Install



www.satelight.com.au
info@satelight.com.au
96 Hudsons Road, Spotswood Vic 3015
Telephone +61 3 9399 5805

Ionic Wall 1600 - Installation Guide



A4 1:1 Scale



www.satelight.com.au
info@satelight.com.au
96 Hudsons Road, Spotswood Vic 3015
Telephone +61 3 9399 5805